

# **ER-MicroCIM User's Manual**

Second Edition

Catalog No. 100095 - Revision B





Copyright ©1996, 2000 Eshed Robotec (1982) Limited

Catalog #100095 Rev.B

(June 2000) Reprinted/PDF version

Every effort has been made to make this book as complete and accurate as possible. However, no warranty of suitability, purpose, or fitness is made or implied. Eshed Robotec is not liable or responsible to any person or entity for loss or damage in connection with or stemming from the use of the software, hardware and/or the information contained in this publication.

Eshed Robotec bears no responsibility for errors which may appear in this publication and retains the right to make changes to the software, hardware and manual without prior notice.



<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	About ER-MicroCIM	1
1.2	Safety	1
1.3	About this Manual	2
<b>2</b>	<b>Operation Scenario</b>	<b>3</b>
<b>3</b>	<b>System Components</b>	<b>4</b>
3.1	Prerequisites	4
3.2	Documentation	4
3.3	Software	5
3.4	Hardware	5
<b>4</b>	<b>Installation</b>	<b>7</b>
4.1	Unpacking	7
4.2	Setup	7
4.3	Hardware Assembly	7
4.3.1	Pneumatic Parts Feeder	7
4.3.2	SCORBOT-ER Vplus Robot	9
4.3.3	Controller-A	9
4.3.4	ASRS	9
4.3.5	Barcode Reader	9
4.3.6	Conveyor Pallets	10
4.3.7	Templates	10
4.3.8	Palletizing (Finished Parts) Rack	10
4.3.9	Computers	10
4.3.10	Vision	10
4.4	Wiring	12
4.5	Software Installation	15
4.5.1	ER-MicroCIM Installation	15
4.5.2	ROBOTVISIONpro Installation	16
4.5.3	ACL Controller Configuration	16
4.6	Teaching Robot Positions	19
4.7	Stand-Alone Testing and Adjustment of Devices	23
4.7.1	Conveyor	23
4.7.2	Barcode Reader	24
4.7.3	Parts Feeder	24
4.7.4	OpenCIM Device Drivers and Vision	25
4.7.5	CIM Manager	28

<b>5</b>	<b>Preparation for On-Line Operation</b>	30
<b>6</b>	<b>User System Operation</b>	33
6.1	System Overview	33
6.2	Activating the System	34
<b>7</b>	<b>Advanced System Operation</b>	36
7.1	System Overview	36
7.2	Modes of Operation	38
7.2.1	Total Simulated Production	38
7.2.2	Total On-Line Production	38
7.2.3	Production with Simulated Vision	38
7.2.4	Production with User (Manual) Vision	38
7.2.5	Robot Only Real Mode	39
7.3	Stand-Alone Operation	40
7.3.1	Stand-Alone Operation - Station 1	40
7.3.2	Stand-Alone Operation - Station 2	41
<b>8</b>	<b>Technical Data</b>	42
8.1	Reports	42
8.1.1	Machine Report	42
8.1.2	Process Report	43
8.1.3	ASRS Report	43
8.1.4	Part Definition Report	44
8.1.5	Sub-Part Report	44
8.1.6	Order Entry Report	45
8.1.7	Aplan Report	45
8.1.8	User Report	46
8.2	Device ID Map	47
8.3	Wiring	48
8.4	Technical Drawings of Parts	51
8.4.1	Plexiglass Base	51
8.4.2	Aluminum Cylinders	52
8.5	Barcode Reader Setup	53
8.6	Known Problems	54
8.6.1	Bug: Incorrect Status in Controller for ACL Program RVP	54
8.6.2	Order Limitation	54
<b>9</b>	<b>Maintenance and Repairs</b>	55
9.1	Hardware	55
9.1.1	Conveyor	55
9.1.2	Robot and Controller	55
9.1.3	Pneumatic System	55
9.1.4	Electrical Wiring	55
9.2	Software and PCs	55
9.2.1	OpenCIM Software	55
9.2.2	Vision System	55

<b>10 Suggested Study Topics</b> . . . . .	<b>56</b>
10.1 Modules . . . . .	56
10.1.1 Robot . . . . .	56
10.1.2 Robot Mechanisms . . . . .	56
10.1.3 PID Control . . . . .	57
10.1.4 Computer Communication . . . . .	57
10.1.5 Pneumatic Systems . . . . .	57
10.1.6 Sensors and PLC Control . . . . .	57
10.1.7 Identification Systems . . . . .	57
10.1.8 Vision and Quality Control . . . . .	58
10.1.9 Manufacturing Software . . . . .	58
10.2 Courses . . . . .	58
10.2.1 AMT: Semester I . . . . .	58
10.2.2 AMT: Semester II . . . . .	59
10.2.3 AMT: Semester III . . . . .	59
10.2.4 AMT: Semester IV . . . . .	59





*Read this manual thoroughly before you install or operate the **ER-MicroCIM**.*

---

## 1.1 About ER-MicroCIM

The **ER-MicroCIM** system demonstrates the integration of various educational disciplines which are usually taught independent of one another. These technologies include robotics, electronics, pneumatics, programmable logic controllers, sensors, machine vision, barcodes, software programming, manufacturing processes, and others.

The **ER-MicroCIM** system is a turn-key, hands-on training installation. It enables direct user access to each component in the integrated system, thus serving to teach the fundamentals of each individual subject.

The system has been designed for centrally controlled assembly of a cylinder within a base. Production orders are defined by the user. A machine vision system performs quality control inspections of the cylinders.

Based on the **Open-CIM** software package, the **ER-MicroCIM** system can be expanded to form a larger computer integrated manufacturing (CIM) system, thereby providing a greater number of applications, and a more comprehensive emulation of a modern manufacturing environment.

---

## 1.2 Safety

Before installing or operating the **ER-MicroCIM**, make sure you have read and understood **all safety guidelines and warnings in the user manuals supplied with the robot/controller** and other system devices.

*Make sure you heed safety warnings at all times!*

To immediate abort all **ER-MicroCIM** activities:

- Press the EMERGENCY button on the **ER-MicroCIM** Control Panel.

This will abort the PLC and the ACL controller, thereby halting all conveyor and robot movement.

*Note:* The program EMERG (which is activated automatically when the software is loaded) must be running in the background; otherwise, pressing the EMERGENCY switch will have no effect. (See Chapter 5.)

To immediate abort all robot programs and motion, do one of the following:

- Press the **Abort** key on the teach pendant, or
- Use the ACL command **A [Enter]** or **[Ctrl]+A**, or
- Press the controller's red EMERGENCY button.

---

## 1.3 About this Manual

This manual describes the components, installation, operation and maintenance of the **ER-MicroCIM** system.

This manual is organized into the following sections:

- Introduction
- Operation Scenario
- System Components
- Installation
- Preparation for On-Line Operation
- User System Operation
- Advanced System Operation
- Technical Data
- Maintenance and Repairs
- Suggested Study Topics

The **ER-MicroCIM** system is preprogrammed to perform the production sequence described below. Users can define the parts, machining processes, and orders, resulting in different production sequences. Robotic (ACL) programs can also be added and modified.

1. The robot takes a template holding a plexiglass base from the ASRS rack, and brings it to the barcode reader.
2. The template's identification code is scanned by the barcode reader.
3. The robot places the template on the loading buffer (Buffer 1).
4. The robot takes a cylinder from the parts feeder, and inserts it into the base on the template at the loading buffer/assembly jig.
5. The robot places the template onto a conveyor pallet. The pallet carries the template with the assembled product, CIM\_PROD, to the vision station.
6. Without being removed from the conveyor, CIM\_PROD is scanned by the vision system.
7. The vision (quality control) inspection has either of two results:
  - If the ✓ side of the cylinder is facing up, the assembly passes the inspection.  
The pallet is released from the vision station, and the template with CIM\_PROD is returned to the ASRS/Assembly Station.
  - If the ✕ side of the cylinder is facing up, the assembly fails the inspection.  
As soon as the system determines a failed assembly, production of a new CIM\_PROD begins immediately. The pallet carrying the failed assembly is released from the vision station and travels around the conveyor until the robot is free. When the robot is free to unload the template, the pallet is halted at the ASRS/Assembly workstation.
8. The robot takes the template from the conveyor, and places it on the unloading buffer (Buffer 2).
9. Depending on the result of the the vision (quality control) inspection, either one of the following will occur:
  - If CIM\_PROD has passed inspection, the robot takes the assembly from Buffer 2 to the palletizing (finished parts) rack.
  - If CIM\_PROD has failed inspection, the robot takes the assembly from Buffer 2 to the trash bin.
10. The robot returns the empty template from Buffer 2 to the ASRS rack.
11. The robot takes a new template with plexiglass base, and begins another production cycle, if required by the production order.

---

### 3.1 Prerequisites

To install and operate the **ER-MicroCIM** system, your facility must provide the following items:

- CIM Manager PC
  - Hardware Requirements: 486, 66MHz, with at least 16MB RAM; at least 30MB available disk space; VGA display adapter; 2 RS232 ports; BUS mouse.
  - Software Requirements: DOS 6.2 or later; Windows for Workgroups 3.11. English versions recommended.
- Vision PC
  - Hardware Requirements: 486, 33MHz, with at least 4MB RAM; at least 4MB available disk space; VGA display adapter; 2 RS232 ports;
  - Software Requirements: DOS 6.2 or later
- 2 Monitor/Keyboard Desks: one desk must be large enough for two monitors (the Vision PC monitor and the video monitor).
- Compressed Air supply: 5-7 bar; 6mm inlet
- AC Power supply and power outlet strip with on/off switch and 6 outlets.

Make sure the voltage settings on the **ER-MicroCIM** equipment match your power supply.

*To ensure proper functioning of the CIM and vision software, be sure your PCs do not contain any additional expansion cards, particularly multimedia, sound and communication cards.*

---

### 3.2 Documentation

A number of publications are provided with the **ER-MicroCIM** system. The following is the list of publications you will need for working with the system:

- *ER-MicroCIM User's Manual* (Catalog #100095)
- *Open-Cim User's Manual* (Catalog #100094)
- *SCORBOT-ER Vplus User's Manual* (Catalog #100016)
- *ACL for Controller-A Reference Guide* (Catalog #100083)
- *ATS for Controller-A Reference Guide* (Catalog #100084)
- *ACLOff-line User's Manual* (Catalog #100051)
- *ROBOTVISIONpro User's Manual* (Catalog #100062)

- *SLC 500™ Module Hardware Style Installation and Operation Manual*, Allen-Bradley (U.S.A. only); or  
*CQMI Programmable Controllers Operation Manual*, OMROM (all countries except U.S.A.)

---

### 3.3 Software

The **ER-MicroCIM** system contains the following software:

- ER-OpenCIM version 1.4
  - Six 3.5" 1.44MB diskettes, including ATS and ACLoff-line software.
  - HASP-3 DEOAX white software protection plug.
- ROBOTVISIONpro version 2.4
  - One 3.5" 1.44MB diskette
  - Gray software protection plug.

---

### 3.4 Hardware

The **ER-MicroCIM** system contains the following hardware:

- Conveyor
  - Closed loop, monorail conveyor.
  - Pallet tracking devices; magnetic sensors, and pneumatic pistons for halting and releasing pallets at station.
  - Programmable Logic Controller (PLC).
  - 2 Pallets.
- Robot Station
  - SCORBOT-ER Vplus robot.
  - Controller-A: Advanced Control Language (ACL version 1.44) command environment (programmed onto an EPROM within the controller). Equipped with auxiliary RS232 communication card.
  - Teach pendant, connected to the controller, for immediate, hand-held access to the controller, especially useful for teaching positions.
  - 2 Buffers; Buffer 1 serves as an assembly jig.
  - ASRS Rack with 6 cells; 6 templates.
  - Palletizing Rack, for assembled parts.
  - Trash Bin, for rejected assemblies.
  - Barcode Reader, for template identification.
  - Parts Feeder; pneumatic-gravity operation.
  - 10 plexiglass bases and 10 aluminum cylinders.

- Vision Station
  - EV681 8-bit frame-grabber
  - RS170 video camera.
  - Composite RS170 video monitor.

The installation procedures will be performed in the following order:

- Hardware assembly
- Wiring
- Software installation
- Teaching robot positions
- Stand-alone testing and adjustment of devices.

---

## **4.1 Unpacking**

Before installing the **ER-MicroCIM**, examine it for signs of shipping damage. If any damage is evident, contact your freight carrier, and begin appropriate claims procedures.

Make sure you have received all the items listed on the shipment's packing list. If anything is missing, contact your supplier.

---

## **4.2 Setup**

Place the **ER-MicroCIM** table within reach of the power supply and the air supply.

For personal safety and sufficient access to the **ER-MicroCIM** from all sides, a free area of at least 1 meter around the table is recommended.

---

## **4.3 Hardware Assembly**

Assemble and install the components in the order presented below. Refer to Figures 1 and 2.

*Be sure you comply with all safety guidelines and warnings in the user manuals supplied with the robot, controller and other devices.*

*Do not make any cable connections unless instructed to do so. Wiring procedures appear in the next section.*

### **4.3.1 Pneumatic Parts Feeder**

The base of the feeder is pre-mounted on the **ER-MicroCIM** table. Four screws have been placed in this base.

1. Attach the feeder chute to the base by means of the four screws.
2. As you tighten the screws, adjust the spacing between the two sides of the chute, to allow the aluminum cylinders to fall freely into the base.




Figure 1: Installation Layout - Side View




Figure 2: Installation Layout - Top View



### 4.3.2 SCORBOT-ER Vplus Robot

Six mounting holes for the robot are predrilled in the **ER-MicroCIM** table. Bolts and nuts have been placed in these holes.

1. Mount the robot on the **ER-MicroCIM** table, according to the installation instructions in the robot's *SCORBOT-ER Vplus User's Manual*.

Position the robot with its cable facing towards the hole in the table.

2. Remove the D50 connector from the end of the robot cable. Insert the cable through the hole in the table. Reattach the D50 connector to the cable.

### 4.3.3 Controller-A

1. Remove the four screws on the controller cover, and lift it off.
2. Install the auxiliary (multi-port) communication card in the controller, according to the instructions in the *SCORBOT-ER Vplus User's Manual*.
3. Connect the I/O box to the ACL controller, as follows. Refer to Figure 7.
  - Make sure the ribbon cable is plugged into the connector marked "Controller (Type A)" in the I/O box.
  - Thread the ribbon cable from the I/O box through one of the open slots on the controller's rear panel.
  - Plug the ribbon cable connector into the I/O connector, which is located between the controller's power/motor switches and transformer.
4. Replace the cover of the controller and tighten the screws.
5. Place the controller on the shelf under the table.
6. Connect the robot and the controller, as follows:
  - Connect the robot's D50 connector to the controller.
  - Connect the teach pendant to the controller.

### 4.3.4 ASRS

Four mounting holes for the ASRS are predrilled in the **ER-MicroCIM** table. Four screws have been taped to the table next to these holes.

Align the ASRS rack with the mounting holes on the table. Using the four screws provided, attach the ASRS rack to the table.

### 4.3.5 Barcode Reader

Two mounting holes for the barcode reader are predrilled in the **ER-MicroCIM** table. Two bolts and nuts have been placed in the holes.

1. Align the holes and the barcode reader stand. Using the two bolts and nuts, attach the stand to the table.

2. Attach the barcode reader to its stand, using the four screws provided with the barcode reader.

*Make sure the barcode scanner window faces the robot.*

3. Insert the barcode reader cable through the hole in the table.

#### **4.3.6 Conveyor Pallets**

The conveyor is pre-mounted on the **ER-MicroCIM** table.

Place the two pallets supplied with system anywhere along the conveyor with the arrow on the pallet pointing in the direction of movement of the conveyor.

#### **4.3.7 Templates**

1. Apply the barcode stickers to the templates, on the side opposite the handle.
2. Using the 11.4mm and 12.7mm metal pins supplied with the system, prepare the six templates for carrying the cylinder-in-base assemblies.

Figure 3 shows the arrangement of the pins on a template. Make sure the pins are arranged identically on each template.

#### **4.3.8 Palletizing (Finished Parts) Rack**

Using the 10.1mm and 12.7mm metal pins supplied with the system, prepare the palletizing rack for holding the cylinder-in-base assemblies.

Make sure the pins are arranged identically for each grid.

Figure 4 shows the arrangement of the pins on the rack.

#### **4.3.9 Computers**

1. Install the frame grabber card in the Vision PC. Follow the instructions in the *ROBOTVISIONpro User's Manual*.
2. The computers may be placed on the shelf under the **ER-MicroCIM** table. The CIM Manager PC should be placed to the right of the ACL controller, and the Vision PC should be placed to the left of the controller.
3. Make sure the cables from the equipment on the **ER-MicroCIM** table can reach the computers.
4. Make sure the cables from the monitors and the inputs devices can reach the computers. Connect the monitor, keyboard and mouse for each computer.

#### **4.3.10 Vision**

Three mounting holes for the camera stand are predrilled in the **ER-MicroCIM** table. Three bolts and nuts have been placed in these holes.

1. Align the holes and the base of the camera stand, and attach.
2. Attach the lens to the camera.

3. Attach the camera to the stand.
4. Place the video monitor on the desk next to the Vision PC monitor.




Figure 3: Layout of Pins on Template




Figure 4: Layout of Pins on Palletizing Rack

---

## 4.4 Wiring

Refer to Figures 5, 6 and 7.

Refer also to Section 8.3, “Wiring,” for additional technical data.

1. Connect the HASP-3 (white) software protection plug to the parallel port on the CIM Manager PC.
2. Below the **ER-MicroCIM** table you will find the RS232 cable from the PLC. Connect the D25 female connector to COM1 on the CIM Manager PC.
3. Connect the RS232 cable (#ER40035) to the ACL controller’s RS232 port and to COM2 on the CIM Manager PC.
4. Connect the braided RS232 cable (#ER40120) to the controller’s auxiliary communication card connector.
5. Using the braided cable, connect COM1 from the controller communication card to COM2 on the Vision PC. (If COM1 on the Vision PC is available, use COM1 instead of COM2.)
6. Connect COM2 from the controller communication card to cable #ER40084. Connect this cable to the barcode reader.
7. Connect the DC cable from the barcode power supply unit to the round plug on the side of the barcode reader’s D-type connector.
8. Connect the power cord from the barcode transformer to the ACL controller’s power outlet.  
  
(If the barcode reader has not been setup by a service technician, refer to the instructions in the Section 8.5, “Barcode Reader Setup.”)
9. Under the table you will find wires with orange terminal blocks.  
Open the I/O Box and connect these terminals as follows. Refer to Figure 7.
  - Connect terminal J10 to Input (Block C) J10.
  - Connect terminal J11 to Input (Block C) J11.
  - Connect terminal J2 to Output (Block A) J2.
  - Connect terminal J1 to User Power Supply J1.
10. Connect the camera and the video monitor to the frame grabber card, according to the instructions in the *ROBOTVISIONpro User’s Manual*.
11. Make the following power supply connections:
  - Connect the controller to the AC power supply.
  - Connect the conveyor transformer to the AC power supply.
  - Connect the computers to the AC power supply.
  - Connect the video monitor to the AC power supply.




Figure 5: ER-MicroCIM Wiring




Figure 6: Vision System Cable Connections




Figure 7: I/O Box Connectors

---

## 4.5 Software Installation

The software installation procedures will be performed in the following order:

- Installation of the **ER-MicroCIM** version of the **Open-CIM** software, on the CIM Manager PC.
- Installation of the **ROBOTVISIONpro** software, **ACL for ACL controller** version, on the Vision PC.
- Configuration of the ACL controller and downloading of data to controller.

### 4.5.1 ER-MicroCIM Installation

Perform the installation from the DOS environment.

*Note:* Software can only be installed to drive C:.

*Note:* During the installation a file named W.BAT is written to drive C:. If a file of that name already exists, rename it before you begin the installation.

1. Insert disk 1 of the **Open CIM** software into the floppy drive of the CIM Manager PC and type: `INSTALL [Enter]`

You will be prompted to insert the remaining disks.

2. When the installation is complete, type: `C:\>W [Enter]`

W.BAT is written to C:\ during the installation. This batch file will load Windows for Workgroups without network drivers.

3. From the Windows Program Manager, select File | New | Group in order to add seven new groups to your Program Manager. Be sure to include the complete path in the Group File field:

<code>C:\opencim\microcim\ws0\ws0.grp</code>	(manager for system supervisor)
<code>C:\opencim\microcim\ws0\user.grp</code>	(manager for user)
<code>C:\opencim\microcim\ws1\ws1.grp</code>	(activates workstation 1)
<code>C:\opencim\microcim\ws1\ws1r.grp</code>	(robot programs at workstation 1)
<code>C:\opencim\microcim\ws1\ws1sys.grp</code>	(system operation at workstation 2)
<code>C:\opencim\microcim\ws2\ws2.grp</code>	(activates workstation 2)
<code>C:\opencim\microcim\ws2\ws2sys.grp</code>	(system operation at workstation 2)

Do not enter any text in the Description field. It has already been defined.

4. Copy all the files in the subdirectory `C:\OPENCIM\WIND!` to `C:\WINDOWS`.
5. Find the **Computer Name** of the CIM Manager PC. It is defined in the Windows **Control Panel | Network | Computer Name** or in the string **ComputerName=** under the heading [Network] in the SYSTEM.INI file in the `C:\WINDOWS\SYSTEM` directory. If the Computer Name does not exist, you must create it by editing the SYSTEM.INI file.

6. In the files C:\OPENCIM\MICROCIM\SETUP\\*.MAP, change all instances of the string WUSER8 to the name of the CIM Manager PC.
7. Create two mailslots and send a message from one to the other. Make sure only one message is received. Refer to the *Open-CIM User's Manual*. (Note that you must use the format \MAILSLOT\NAME! when creating more than one mailslot on one PC.)

#### 4.5.2 ROBOTVISIONpro Installation

Install the ROBOTVISIONpro software according to the instructions in the *ROBOTVISIONpro User's Manual*, and the following:

1. Accept the default path C:\RVPRO as the software directory for the installation.
2. When you are prompted for the **Robot Type**, select **ACL for ACL controller**.
3. When you are prompted to run the **SETUP** program, click on **No**. The installation will end and exit to DOS.
4. Copy the file C:\OPENCIM\MICROCIM\WS2\RVPWKS\MICROCIM.WKS from the CIM Manager PC to the directory C:\RVPRO in the Vision PC.

#### 4.5.3 ACL Controller Configuration

1. From DOS in the CIM Manager PC, activate Windows for Workgroups without network drivers. Type:

```
C:\>w [Enter]
```

2. Open the **Robot Programs WS1** group window. See Figure 8.




Figure 8: Robot Programs at Workstation 1 Group Window

Click on the **ATS** icon. The ATS main screen will open.

3. Press [Ctrl]+F1 to configure Controller-A.  
Press Y to confirm the prompt to configure the controller.



You are then prompted by a short series of Controller Configuration options. See Figure 9.

```
Robot type: ER V / ER Vplus / ER VII / OTHER
```

Make sure **ER-Vplus** is selected, and press [Enter].

```
How many axes are installed (8)? ..
```

Type **6** and press [Enter].

```
Is expanded memory installed?(Y/N)?Y
```

Press **Y** or [Enter].

```
Does the controller have an auxiliary RS232 board?(Y/N)?N
```

Press **Y**.

```
Working directory is: C:\opencim\microcim\wsl\robot1
```

```
Is this correct (Y/N)?Y
```

Press **Y** or [Enter].

```
WARNING! ...
```

```
ARE YOU SURE (Y/N)?N
```

Press **Y**.

ATS will now perform the configuration.

You can ignore the message about the missing SETUP.PAR parameter file.

4. When the > prompt appears, press [Shift]+F10.

The ATS Backup Manager screen will open. Make the following selections and entries:

```
Backup directory: C:\opencim\microcim\wsl\robot1
```

Make sure the path correctly shows the working directory defined during the configuration, as shown here.

```
Backup / Restore: ALL
```

Use the arrow keys to highlight **ALL** and press [Enter].

```
During Restore: ERASE.
```

Use the arrow keys to highlight **ERASE** and press [Enter].

```
File name: all
```

Type **all** and press [Enter].

Press [Enter] again. Press **F5** to **RESTORE from disk**.

Press **Y** to confirm all prompts to overwrite and erase.

This file named **ALL.CBU** will now be downloaded from the CIM Manager PC to the ACL controller. This file contains all programs, positions and parameters required for controller operation in the **ER-MicroCIM** environment.

## 4.6 Teaching Robot Positions

In this part of the installation, you will adjust the values (coordinates) of the positions which were downloaded to the controller.

*Note:* Downloading the ALL.CBU file changed the value of controller parameter PAR 52. The default PAR 52=0 is changed to PAR 52=4214. Before you record robot positions for the **ER-MicroCIM**, you should check the value of parameter 52 by entering the ACL command:

```
SHOW PAR 52
```

1. The teaching of robot positions is performed from **Robot Program WS1 | ATS**.
2. Enter the ACL command:

```
RUN HOMES
```

Wait until the robot has completed the homing twice.

3. All positions used in the **ER-MicroCIM** belong to the vector CIM[200]. To teach the robot the positions required for the application, you must attach this vector to the teach pendant.

Enter the ACL command:

```
ATTACH CIM
```

3. Figure 10 and the following Positions Table show the numbers of the positions which must be recorded before the assembly operation can be executed.




Figure 9: Part Positions

Note the following part ID numbers:

- The plexiglass base part ID number is 1
- The cylinder part ID number is 2.

The part ID numbers (*PID* in Figure 10) determine the name (number) of the various positions in the **ER-MicroCIM** cell.

Figure 11 illustrates the order in which positions should be taught.




Figure 10: Position Teaching Sequence

ER-MicroCIM Positions							
Description of Position	Device ID*	Device Index*	GET P1	Above GET P2	PUT P1	Above PUT P2	
Template on pallet at workstation	1	1	1	11	1	11	
Template in front of barcode reader. (Movement between position 10 and position 20 must cross the laser beam.)	9	1	10	20	10	20	
Template on buffer	5	1	2	12	2	12	
Template on buffer/jig	4	1	3	13	3	13	
Cylinder in base on template on buffer/jig	4	1			142	152	
Plexiglass base on template on buffer	5	1	21	31			
Feeder	6	1	92	93			
Trash Bin	7	1			90	91	
Assembled Cylinder-in-Base on Palletizing Rack	8	1			101	111	
	8	2			102	112	
	8	3			103	113	
	8	4			104	114	
	8	5			105	115	
	8	6			106	116	
			<b>At P1</b>	<b>Above P2</b>	<b>Approach/ Retreat P3</b>	<b>In Free Movement Zone P4</b>	
Template on ASRS Rack	Cell 1 **	3	1	61	71	81	171
	Cell 2	3	2	62	72	82	172
	Cell 3	3	3	63	73	83	173
	Cell 4	3	4	64	74	84	174
	Cell 5	3	5	65	75	85	175
	Cell 6	3	6	66	76	86	176

\* Refer to Section 8.2, "Device ID map."  
\*\* Cell 1 is on the bottom left side of the ASRS rack.

3. When you have finished recording the positions, use the ATS Backup Manager to save the programs, positions and parameters to disk. *Save each item as a separate file.*

Make the following selections and entries:

Backup directory: C:\opencim\microcim\wsl\robot1

Backup / Restore: ALL

File name: all

Press [Enter] again. Press **F3** to **SAVE to disk**

Backup / Restore: PROGRAMS

File name: programs

Press [Enter] again. Press **F3** to **SAVE to disk.**

Backup / Restore: POSITIONS

File name: position

Press [Enter] again. Press **F3** to **SAVE to disk.**

Backup / Restore: PARAMETERS

File name: paramete

Press [Enter] again. Press **F3** to **SAVE to disk**

---

## 4.7 Stand-Alone Testing and Adjustment of Devices

In this part of the installation, you will test each device individually to make sure it is functioning properly.

1. Turn on the **ER-MicroCIM** power supply.

The conveyor will move for 60 seconds, and then stop.

*If the Auto/Manual button on the conveyor's control panel is set to Manual when power is turned on, the conveyor will not move.*

2. Check the following:
  - Make sure all devices are turned on.
  - Make sure there is no movement of any other device in the system.
3. You may now proceed to check the devices in the following order:

### 4.7.1 Conveyor

Refer to Figure 12.

1. Switch the Auto/Manual button on the conveyor's control panel to Manual. Then press Start.

Check the following:

- The conveyor is moving clockwise.
- The pistons at both stations on the conveyor extend and stop the pallets, and then retract and release the pallets.
- The conveyor stops when you press Stop and restarts when you press Start. Stop and start the conveyor several times.




Figure 11: Control Panel

2. Make sure the Auto/Manual button on the conveyor's control panel to Manual. Then press Start.

While the conveyor is moving, press the emergency button and check the following:

- The emergency button remains locked.
- The LED for input 1 on the ACL controller is lit.
- The conveyor stops.

Release the emergency button, and check the following:

- The LED for input 1 on the ACL controller turns off.
- The conveyor restarts, or can be restarted.

### 4.7.2 Barcode Reader

From the **Robot Programs WS1** window, activate ATS.

1. Enter the ACL command to turn on the barcode reader:

```
RUN BCON
```

Make sure the red light on the rear of the barcode reader is lit.

2. Make sure the robot has been homed, and is free to move to position 15.

Enter the ACL commands:

```
SPEED 30  
MOVE CIM[15]
```

3. When the robot reaches reaches position 15, take a template which has a barcode sticker and place it in the robot's grasp.

4. Enter the ACL commands:

```
MOVE CIM[20]  
SPEED 5  
MOVE CIM[10]
```

Make sure you hear the beep when the barcode is read.

5. Enter the ACL command to turn off the barcode reader:

```
RUN BCOFF
```

Make sure the red light on the rear of the barcode reader goes off.

### 4.7.3 Parts Feeder

From the **Robot Programs WS1** window, activate ATS.

1. Make sure output 1 is turned off. Enter the ACL command:

```
SET OUT[1]=0
```

2. Place at least one aluminum cylinder in the parts feeder chute.

3. Enter the ACL command which causes the cylinder to drop down from the chute:

```
SET OUT[1]=1
```

4. Enter the ACL command to push the cylinder out of the feeder:

```
SET OUT[1]=0
```

5. As the cylinder is pushed out of the feeder, make sure it activates the proximity sensor switch, by checking the following:

- The LED near the sensor cable lights up.
- The LED for input 2 on the ACL controller lights up.

If the switch has not been activated, adjust the position of the sensor by turning it.

If the sensor LED lights up, but the input LED does not, make sure both the sensor and the controller input are operating in the same logic mode (PNP or NPN).

#### 4.7.4 OpenCIM Device Drivers and Vision

1. Open the **System Station 1** group window. See Figure 13.




Figure 12: System at Station 1 Group Window

This group allows you to operate each of the **ER-MicroCIM** device drivers in each of three modes (except for the barcode, which has two modes).

- Real Mode: on-line operation.
- Manual Mode: off-line step-by-step software operation; the item description has the suffix **ma**.
- Simulation: off-line software operation; the item description has the suffix **si**.

You will now activate the device drivers in Real Mode, and check whether they actually operate the devices.

2. Click on the **PLC** icon to load the **PLC Device Driver**.

From the **PLC Control Panel**, send an empty pallet to workstation 1.

- Select **Station 1** and click on [**GetFree**].

3. Make sure there is a template with a plexiglass base in Cell 1 of the ASRS.

Make sure there is at least one cylinder in the parts feeder.

Click on the **Terminal ACL** icon to load the **ACL Device Driver**.

You will now check whether the robot can perform all pick and place operations required for assembly and loading in the preprogrammed production sequence.

Click on [**Enter P/P Cmd**] to open the **Run 'Pick and Place'** window. Now make the following selections:



	<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>
<b>Part ID</b>	template (0)	template (0)	cylinder_sup (11)	template (0)
<b>Source ID</b>	asrs (3)	barcode (9)	feeder (6)	assembly buffer (4)
<b>Source Index</b>	1	1	1	1
<b>Target ID</b>	barcode (9)	assembly buffer (4)	assembly buffer (4)	conveyor (1)
<b>Target Index</b>	1	1	1	1
<b>Note</b>	0	0	0	0
	<b>OK</b>	<b>OK</b>	<b>OK</b>	<b>OK</b>
<b>Result:</b>	Robot takes a template with base from ASRS rack, and brings it to the barcode reader.	Robot places the template on the assembly jig.	Robot takes a cylinder from the feeder and places it on the base.	Robot places the loaded template on the conveyor.

4. From the **PLC Control Panel**, send the loaded pallet to workstation 2.

- Select **Station 1** and click on [**Deliver**].
- Select **Station 2** and click on [**Release**].

The pallet will stop under the camera at the Vision/QC workstation.

5. In the Vision PC activate **ROBOTVISIONpro** (RVPRO.EXE) .

- Select **OPTIONS | Workspace**.
- Click on [**Load ...** ].
- Select the file **MICROCIM.WKS** and click on [**Ok**] to load the file.

Select **IMAGE |Setup | Define Frames**.

- Press **Snap** and watch the video monitor to check the camera's field of view. Adjust the position of the camera so that the assembly is within the camera's field of view. Select **Frame 1** and adjust the size of the frame around the cylinder.
- Select **Save** to save the frame information in a file. Use the name **MICROCIM.FRA**.
- Click on [**Ok**] to exit this screen.

Select **IMAGE | Setup | Image Histogram**.

Select **IMAGE | Setup | Image Histogram**.

- Do not do anything. Simply let the software automatically adjust the offset and the gain.
- Click on [**Ok**] to exit this screen.

Select **IMAGE | Binary | Binary Level**.

- Click on [**Binarization**]. Move the line cursor on the histogram until you see a clearly defined black and white image of the mark on the cylinder.

Select **PATTERN | Identification**

- Click on [**Identify**] and check whether the vision system can identify the ✓ and the ✕ sides of the cylinder.
  - ✓ Object name = QCPASS
  - ✕ Object name = QCFAIL.
- Turn the cylinder over. Click on [**Start New Cycle**]. You will see the other marking. Check whether the correct object name is displayed.

*Note:* If the system is unable to identify the ✓ or ✕, do the following:

- Select **OPTIONS | Image Options**.  
Change the value of **Min. Area** to 1000.  
Change the value of **Min. Perimeter** to 500.
- Again select **PATTERN | Identification**, and click on [**Identify**] to check whether the vision system can identify the ✓ and the ✕. When successful, proceed to save the workspace.

Save the current workspace.

- Select **OPTIONS | Workspace**.
- Click on [**Save ...**].
- Select **VISION.WKS** and click on [**Ok**] to save the file.

Exit the **ROBOTVISIONpro** software.

6. Now return to the CIM Manager PC.

From the **PLC Control Panel**, send the loaded pallet back to workstation 1.

- Select **Station 1** and click on [**Deliver**].
- Select **Station 2** and click on [**Release**].

The pallet will stop at the robot workstation.

7. Select the **Run 'Pick and Place'** window at the CIM Manager PC.

You will now check whether the robot can perform all pick and place unloading operations required in the preprogrammed production sequence.

In the **Run 'Pick and Place'** window make the following selections:

	<b>E</b>	<b>F</b>	<b>G</b>	<b>H</b>
<b>Part ID</b>	template (0)	plexiglass_sup (1)	plexiglass_sup (1)	template (0)
<b>Source ID</b>	conveyor (1)	buffer (5)	buffer (5)	buffer (5)
<b>Source Index</b>	1	1	1	1
<b>Target ID</b>	buffer (5)	rack (8)	trash bin (7)	ASRS (3)
<b>Target Index</b>	1	1	1	1
<b>Note</b>	0	0	0	0
	<b>OK</b>	<b>OK</b>	<b>OK</b>	<b>OK</b>
	Robot takes template from conveyor and places it on buffer.	Robot takes assembled part from buffer to finished parts rack.	Robot takes assembled part from buffer to trash bin.	Robot returns the empty template to Cell 1 in ASRS.

- Close the **Virtual ACL Driver** window. This will close the **ACL Control Panel**.  
Close the **Virtual PLC Driver** window. This will close the **PLC Control Panel**.

#### 4.7.5 CIM Manager

The modules and functions in the **CIM Manager** are explained in Chapter 7, “Advanced System Operation.”

- From the **MicroCIM System Manager** window, do the following:
  - Click on **VC2SIMAP**. A DOS box will appear for a few seconds.
  - Click on **Storage Refresh**. A DOS box will appear for a few seconds.
  - Click on **Start CIM (simulation)**. Device drivers will be loaded and the **OpenCIM System Manager** screen is displayed. See Figures 14 and 15.




Figure 13: System Manager Group Window

2. From the **Open-CIM Manager** window, do the following:
  - Click on the yellow lightning bolt. This sends a command to reset (INIT) all device drivers. The run arrow will now turn green. Three windows also cascade onto the screen:

- Program View
- Log View
- Order View

These windows show the status of work in progress; they are for viewing only.

- Click on the green run arrow. The || pause button will now turn blue. The **Leaf View** window will now also appear.
- Watch the screen and wait until a box appears with the message:

CIM\_PROD HAS BEEN FINISHED

Click on [Ok]. Another message appears:

ORDER HAS BEEN FINISHED

3. Close the **Open-CIM Manager** and all drivers which appear in the **Task List**.
4. Click on **MicroCIM System Manager | VC2RE.MAP**. A DOS box will appear for a few seconds. This will prepare system for on-line operation (as detailed the following chapters.)




Figure 14: Open-CIM Manager

---

---

# 5

## *Preparation for On-Line Operation*

At the start of every on-line work session, the following procedures must be performed.

1. Turn on the power supply. Make sure all devices, computers, and the controller are turned on and ready for operation.
2. Activate the **Open-CIM** software:  
On the CIM Manager PC, do the following:
  - From the DOS prompt, type: **w [Enter]**.  
(This is the same as activating Windows by means of the command WIN /n).
  - Open the **Program Manager-System Station 1** group window.
  - Click on **Terminal ACL** to load the **ACL Device Driver**.
3. Home the robot:
  - Make sure the controller is in the CON state (Control Enabled). From the **ACL Control Panel**, enter the command: **CON**
  - Using the teach pendant, bring the robot to the area above the buffers (Free Movement Zone), so that the homing operation can safely begin.
  - Home the robot: From the **ACL Control Panel**, enter the command: **RUN HOMES**.
  - Make sure the teach pendant is set to **Joint Mode**.
4. Check controller status:
  - Maximize the the **Virtual ACL Driver** window.
  - From the **ACL Control Panel**, enter the command: **STAT**
  - Make sure the system displays the response:

Job Name	Priority	Status
RVP	000005	Delay
EMERG	000005	Trigger
  - Close the **ACL Virtual ACL Driver** window.

5. Send a loaded pallet to workstation 2
  - Place a template with an assembled part, CIM\_PROD, on pallet closest to the vision station:
  - Click on **PLC** to load the **PLC Device Driver**. See Figure 16.
  - Select Station **2** and click on [**GetFree**]. This will send the pallet to the vision station.




Figure 15: PLC Device Driver Control Panel

6. Prepare the vision station:
  - From the ROBOTVISION directory (C:\>RVPRO) in the Vision PC, activate **ROBOTVISIONpro**, type: RVP [Enter].
  - Select **IMAGE | Setup | Image Histogram**.  
Do not do anything. Simply let the software automatically adjust the offset and the gain. Click on [**Ok**] to exit this screen.
  - Select **IMAGE | Binary | Binary Level**.  
Click on [**Binarization**]. Move the line cursor on the histogram until you see a clearly defined black and white image of the mark on the cylinder.
  - Select **PATTERN | Identification**  
Click on [**Identify**] and check whether the vision system can identify the ✓ and the ✕ sides of the cylinder.
    - ✓ Object name = QCPASS
    - ✕ Object name = QCFAIL.
  - Turn the cylinder over. Click on [**Start New Cycle**]. You will see the other marking. Check whether the correct object name is displayed.
  - Select **ROBOT | Automatic Mode**.
    - Press [Enter].

Make sure you see the ACL prompt, >, in the upper text box. See Figure 17.




Figure 16: ROBOTVISIONpro Automatic Mode Screen

## 7. Templates and Parts

- Place a plexiglass base on each of the six templates .
- Place the six loaded templates into the six cells on the ASRS rack. Make sure the barcode on the template faces away from the robot, and the handle faces the robot.
- Fill the parts feeder with the cylinders.
- Make sure there are no parts or templates anywhere in the cell (except in the feeder and ASRS rack).

## 8. Pallets and Buffers

- Place the two pallets anywhere along the conveyor. Make sure the arrow on the pallet is facing in the same direction as the movement of the conveyor.
- Make sure the two buffers are empty.

This chapter provides basic instructions for activating the **ER-MicroCIM** system and running the preprogrammed production sequence.

## 6.1 System Overview

Open the **User** group window. See Figure 18.

This group contains basic applications required for on-line operation of the **ER-MicroCIM** system. The following is a brief description of the modules and features which are available in this group.




Figure 17: User Operations Group Window

Icon	Description
OpenCIM Help	On-line help file.
Machines	Defines the machines and processes.
PartDef	Defines the materials which will be used and the parts which will be produced.
Asrs	Defines the contents of the ASRS.
Orders	Defines the production order.
Storage Refresh	Initializes the storage database of the entire system.
OpenCIM Reports	Generates reports.
Start CIM	Loads all device drives, including CIM Manager.
Manager	Loads CIM Manager only.

Complete descriptions of the modules can be found in the *Open-CIM User's Manual*.



---

## 6.2 Activating the System

1. Make sure you have clicked on **MicroCIM System Manager | VC2RE.MAP** and the DOS box appeared for a few seconds.
2. From the **User** group window, do the following:
  - Click on **Storage Refresh**. A DOS box will appear for a few seconds.

This serves to clear the buffers, pallets and robot of all parts and templates. In addition, it resets the ASRS cells to the status required for the start of production.
  - Click on **Order**. The **Order Definition** screen will appear showing an order for the CIM\_PROD cylinder-in-base assembly.
    - Bring the cursor to the **Total Qty** field, and from the keyboard enter the number of items you want to produce.
    - Click on [**Submit**]. You will see the message:

Done
    - Close the **Order Definition** window.
  - Click on **Start CIM**. Device drivers will be loaded and the **Open-CIM Manager** screen will appear. A small **Debug** window also opens (hidden behind the **Open CIM Safety** message box) which serves to display data which is being communicated.
3. From the **Open-CIM Manager** window, do the following:
  - Click on the yellow lightning bolt. This sends a command to reset (INIT) all device drivers. The run arrow will now turn green. Three windows also cascade onto the screen:
    - Program View
    - Log View
    - Order View

These windows show the status of work in progress; they are for viewing only. They are described in detail in the *Open-CIM User's Manual*.

Figure 19 shows the Program View window for CIM\_PROD before the green run button is pressed; Figure 20 shows the same window after the button is pressed. Note that lines scroll up from bottom to top.

  - Click on the green run arrow. The || pause button will now turn blue. The **Leaf View** window will now also appear.
4. While the order is being manufactured, you can track production by looking at the four different **View** screens. Again, refer to the *Open-CIM User's Manual*.)

You can also observe the quality control inspections on the Vision PC monitor.

Watch the CIM Manager PC monitor and wait until a box appears with the message:

```
CIM_PROD HAS BEEN FINISHED
```

Click on [**Ok**]. Another message appears:

ORDER HAS BEEN FINISHED

5. To produce additional CIM\_PROD, do the following:

- Close the **Open-CIM Manager**.
- Click on **Storage Refresh**.
- Click on **Order** to open the **Order Definition** screen. Change the total quantity, if desired, and click on [**Submit**], and close the window.
- Click on **Manager** to open the **Open-CIM Manager** screen. Start production as you did previously.

Level	PART	ACTION	SUBPART	TARGET	#	PARAMETERS	P1	P2	P3	P4
1		TopBatch	BATCH	1	1	1				
2	CIM_PROD/1	MAKE	CIM_PROD/1	1		1.1.1.P.1.00:00				
3	CIM_PROD/1.1	NEXT								
4	CIM_PROD/1.1	PLACE	PLEXIGLAS	RACK1						
5	CIM_PROD/1.1	RENAME	PLEXIGLAS							
6	CIM_PROD/1.1	VISION	PLEXIGLAS		1					
7	CIM_PROD/1.1	ENDPACK	PLEXIGLAS	ASMBUF						
8	CYLINDER_SUP/1	PACK	CYLINDER	PLEXIGLAS	1					
9	CYLINDER_SUP/1	GET	CYLINDER	FDR1						
8	CIM_PROD/1.1	BASE	TEMPLATE	ASMBUF						
9	CIM_PROD/1.1	READC	PLEXIGLAS			STEMPLATETY				
10	CIM_PROD/1.1	GET	PLEXIGLAS	ASRS						

Figure 18: Program View Window for CIM\_PROD

Level	PART	ACTION	SUBPART	TARGET	#	PARAMETERS	P1	P2	P3	P4
1		TopBatch	BATCH	1	1	1				
2	CIM_PROD/1	MAKE	CIM_PROD/1	1		1.1.1.P.1.00:00				
3	CIM_PROD/1.1	NEXT								
4	CIM_PROD/1.1	PLACE	PLEXIGLAS	RACK1						
5	CIM_PROD/1.1	RENAME	PLEXIGLAS							
6	CIM_PROD/1.1	VISION	PLEXIGLAS		1					
7	CIM_PROD/1.1	ENDPACK	PLEXIGLAS	ASMBUF						
8	CYLINDER_SUP/1	PACK	CYLINDER	PLEXIGLAS	1		Wait			
9	CYLINDER_SUP/1	GET	CYLINDER	FDR1						
8	CIM_PROD/1.1	BASE	TEMPLATE	ASMBUF						
9	CIM_PROD/1.1	READC	PLEXIGLAS			STEMPLATETY				
10	CIM_PROD/1.1	GET	PLEXIGLAS	ASRS						

Figure 19: Program View Window for CIM\_PROD

This chapters provides descriptions and instructions for advanced level operating procedures in the **ER-MicroCIM** system.

## 7.1 System Overview

Open the **MicroCIM System Manager** group window. See Figure 21.




Figure 20: System Manager Group Window

This group contains the modules and features which enable advanced level on-line operation of the **ER-MicroCIM** system. The following is a brief description of the modules and features which are available in this group.

Icon	Description
OpenCIM Help	On-line help file.
Machines	Defines the machines and processes.
PartDef	Defines the materials which will be used and the parts which will be produced.
Asrs	Defines the contents of the ASRS.
Orders	Defines the production order.
Storage Refresh	Initializes the storage database of the entire system.

OpenCIM Reports	Generates reports.
Start CIM Manager	Loads all device drives, including CIM Manager.
VC2SIMAP	Loads CIM Manager only.
VC2REMAP	Produces a listing of all device drivers used in simulation mode and writes it to the file VC2.MAP.
VC2CHMAP	Produces a listing of all device drivers used in on-line mode and writes it to the file VC2.MAP.
VC2CHMAP	Produces a listing of all device drivers used when workstation 1 is in on-line mode, and workstation 2 is in either simulation or manual mode, and writes it to the file VC2.MAP.
Edit VC2MAP	Opens Notepad for editing VC2.MAP file.
PNP	Generates pick and place reports and writes them to the subdirectory LOG.
Start CIM RVPsi	Generates pick and place reports and writes them to the subdirectory LOG.
Start CIM RVPma	Loads CIM Manager and all device drivers; vision device driver is in simulation mode.
Start CIM (simulation)	Loads CIM Manager and all device drivers; vision device driver is in manual mode.
Robot Only Real Mode	Loads CIM Manager and all device drivers in simulation mode.
Log OK	Loads CIM Manager and all device drivers in simulation mode; except robot device driver which loads in on-line mode.
Log Not OK	Generates pick and place reports and writes them to the subdirectory LOG.
	Generates pick and place and database reports and writes them to the subdirectory LOG.

Complete descriptions of the modules can be found in the *Open-CIM User's Manual*.

---

## 7.2 Modes of Operation

The **ER-MicroCIM** system can be operated in numerous ways. Following are five possible modes of operation.

### 7.2.1 Total Simulated Production

All device drivers operate in simulation mode. No equipment is used. No product is actually manufactured.

The procedure for activating this mode of operation is detailed in Section 4.7.5, “Stand-Alone Testing/ CIM Manager.”

### 7.2.2 Total On-Line Production

All device drivers operate in on-line mode. All equipment is used. Products are actually manufactured.

The procedure for activating this mode of operation is detailed in Section 6.2, “Activating the System.”

### 7.2.3 Production with Simulated Vision

Robot, barcode reader, and conveyor device drivers operate in on-line mode.

The vision device driver operates in simulation mode.

The production takes place normally, but when the template reaches the vision station, it will stop for a moment, and then continues as if it has passed or failed the quality control inspection, according to a failure rate which has been predefined in the file RVPRSI.INI.

The procedure for activating this mode of operation is as follows:

- **VC2CHMAP**
- **Storage Refresh**
- **Order**
- **Start CIM RVPsi**

To produce additional CIM\_PRODs in this mode, do the following:

- Close the **Manager** window
- **Storage Refresh**
- **Order**
- **Manager**

### 7.2.4 Production with User (Manual) Vision

Robot, barcode reader, and conveyor device drivers operate in on-line mode.

The vision device driver operates in software manual mode.

The production takes place normally, but when the template reaches the vision station, it will stop and wait for the user to determine whether the assembly passes (succeeds) or fails the quality inspection.

The procedure for activating this mode of operation is as follows:

- **VC2CHMAP**
- **Storage Refresh**
- **Order**
- **Start CIM RVPma**
- When the CIM\_PROD is at the vision station, look to see which side is facing the camera. From the CIM Manager PC, bring up the **Virtual RVP Device Driver**.
- From the RVP Control Panel click on either [**Success**] or [**Fail**] according to the ✓ or **X** .

To produce additional CIM\_PRODs in this mode, do the following:

- Close the **Manager** window
- **Storage Refresh**
- **Order**
- **Manager**
- From the RVP Control Panel click on either [**Success**] or [**Fail**] according to the ✓ or **X** .

### 7.2.5 Robot Only Real Mode

Loads CIM Manager and all device drivers in simulation mode, except robot device driver which loads in on-line mode.

Barcode reader, vision and conveyor device drivers operate in simulation mode.

Only the robot operates on-line, but without handling any parts.

*Remove an empty pallet from the conveyor, and place it at Workstation 1.*

The procedure for activating this mode of operation is as follows:

- **VC2SIMAP**
- **Storage Refresh**
- **Order**
- **Robot Only Real Mode**

To produce additional CIM\_PRODs in this mode, do the following:

- Close the **Manager** window
- **Storage Refresh**
- **Order**
- **Manager**

---

## 7.3 Stand-Alone Operation

Each workstation can be operated individually or as a stand-alone system.

### 7.3.1 Stand-Alone Operation - Station 1

Open the **Open CIM Station 1** group window. See Figure 22.



Figure 21: Workstation 1 Group Window

This group contains the modules and features which enables students to operate Workstation 1 as a stand-alone system.

Workstation 1 contains the following elements:

- Robot
- Parts Feeder
- Barcode Reader
- Conveyor (PLC)

The procedure for activating this mode of operation is as follows. See Figure 23.

- Double click on **Start Station 1**. The **ACL Control Panel** and the **PLC Control Panel** will open.
- In the **ACL Control Panel**, enter the ACL command:

```
RUN HOMES
```

Wait until the robot has completed the homing twice.

- Click on [**Enter P/P Cmd**].  
The **Run 'Pick and Place'** window will open.

All robot operations can now be activated from the **Run 'Pick and Place'** window.

The **PLC Control Panel** monitors and controls the movement of all pallets on the conveyor.




Figure 22: Workstation 1 - Stand-Alone Operation

### 7.3.2 Stand-Alone Operation - Station 2

Workstation 2 is a complete vision system. To operate Workstation 2 as a stand-alone system, you will work directly on the Vision Computer, and perform all operations as described in the *ROBOTVISIONpro User's Manual*.

Place a light table or a small board on the conveyor, under the camera. Be sure that the conveyor will not be moved during.

Alternately, you can turn the camera away from the conveyor and work on another table-top. Be certain you can and will return the camera to its proper position in order to resume integrated use of the **ER-MicroCIM** system.



## 8.1 Reports

From either the **User** or **System Manager** group window, click on the **OpenCIM Report** icon to open the **Open-CIM Report Generator** menu. See Figure 24.

The Report Generator allow you to view all data and definitions in the **ER-MicroCIM** environment.

Figures 25 through 31 show the reports which result from the sample application supplied with the system.




Figure 23: Report Generator Menu

### 8.1.1 Machine Report

The Machine Report lists the names of all machines in the **ER-MicroCIM** environment.




Figure 24: Machine Reports

### 8.1.2 Process Report

The Process Report shows the user defined name (Process Name field) of each machines and the process performed by the machine.

#	Machine Name	Process Name	ProcessType	Program File Name
1	RDR1	READC	QC	
2	VSN1	VISION	QC	

Figure 25: Process Report

### 8.1.3 ASRS Report

The ASRS Report shows the contents of the ASRS automatical storage and retrieval system.

Name	Index	Part Name	Part ID	Status	Template Number
ASRS	1	PLEXIGLASS_SUP	0	Part on Template	010001
ASRS	2	PLEXIGLASS_SUP	0	Part on Template	010002
ASRS	3	PLEXIGLASS_SUP	0	Part on Template	010003
ASRS	4	PLEXIGLASS_SUP	0	Part on Template	010004
ASRS	5	PLEXIGLASS_SUP	0	Part on Template	010005
ASRS	6	PLEXIGLASS_SUP	0	Part on Template	010006

Figure 26: ASRS Report

### 8.1.4 Part Definition Report

The Part Definition Report shows the names and descriptions of all parts used in the ER-MicroCIM. It lists parts in all stages of production.

#	Part Name	Type	Part ID	Template ID	Part Description
1	CYLINDER_SUP	Supplied	11	01	CYLINDER FROM THE FEEDER
2	PLEXIGLASS_SUP	Supplied	1	02	PLEXIGLASS_SUP FROM THE ASRS
3	CIM_PROD	Product	21	01	CIM PRODUCTION
4	ERRTMPL	Phantom	99	99	ERROR TEMPLATE
5	ERRCIM	Phantom	93	01	ERROR CIM PRODUCT
6	CIM1_PROD	Product	22	01	ASRS - VISION - ASRS
7	BOX	Supplied	2	02	SUPPLIED BOX + BAR

Figure 27: Part Definition Report

### 8.1.5 Sub-Part Report

The Sub-Parts Report is a Bill of Material. It shows all the sub-parts which comprise the finished product.

Part Name	Sub-Part Name	Manufacturing Process Name	Manufacturing Parameters
CIM_PROD	PLEXIGLASS_SUP	READC	\$TEMPLATETYPE
	ERRTMPL	ONFAIL	ASRS
	CYLINDER_SUP	ASSEMBLY	
		VISION	1
	ERRCIM	ONFAIL	TRASH1
CIM1_PROD	PLEXIGLASS_SUP	READC	\$TEMPLATETYPE
	ERRTMPL	ONFAIL	ASRS
		VISION	1
	ERRCIM	ONFAIL	TRASH1
		TARGET	ASRS

Figure 28: Sub-Part Report

### 8.1.6 Order Entry Report

The Order Entry Report displays the production order which is currently on the shop floor. This order will be put into production whenever the CIM Manager issues a command to start production.




Figure 30: Order Report

### 8.1.7 Aplan Report

The file APLAN.DBF in the WORK directory is a production task list which is created by the system when an order is submitted. It shows the sequence of operations to make each component and/or assemble components into a final product.





Figure 29: Aplan Report

### 8.1.8 User Report

The User Report resembles the Part Definition Report, except that it is organized according to the Part ID numbers.



The screenshot shows a software window titled "Open-CIM Report Window". At the top, there is a status bar with navigation icons and a table showing "Read Selected Total %" with values "7 7 7 100" and "Page 1 of 1". The main content area features the "ESHED ROBOTEC" logo and the title "Open-CIM: Part Definition Report" with a print date of "12/14/95". Below this, the report is sorted by Part ID and contains a table with 7 rows of data.

#	Part Name	Type	Part ID	Template ID	Part Description
1	PLEXIGLASS_SUP	Supplied	1	02	PLEXIGLASS_SUP FROM THE ASRS
2	BOX	Supplied	2	02	SUPPLIED BOX + BAR
3	CYLINDER_SUP	Supplied	11	01	CYLINDER FROM THE FEEDER
4	CIM_PROD	Product	21	01	CIM PRODUCTION
5	CIM1_PROD	Product	22	01	ASRS - VISION - ASRS
6	ERRCIM	Phantom	93	01	ERROR CIM PRODUCT
7	ERRTMPL	Phantom	99	99	ERROR TEMPLATE

Figure 31: User Report

## 8.2 Device ID Map

The file DEVICE.DMC in the SETUP directory contains the device names and ID numbers which you will need when creating or modifying applications.

The following list and Figure 33 show the devices defined for the sample application supplied with the system.

Definition		Description
CNV1	001	1 Conveyor
ASRS	003	3 ASRS Rack
ASMBUF	004	4 Assembly Jig
BFFR1	005	5 Unloading Buffer
FDR1	006	6 Parts Feeder
TRASH1	007	7 Trash Bin
RACK1	008	8 Palletizing Rack
RDR1	009	9 Barcode Reader
ROBOT1	011	11 Robot
VSN1	012	12 Vision System




Figure 32: Device ID Map

## 8.3 Wiring

Figure 34 is a schematic diagram of the system wiring; these wires are located within the conveyor. The table which follows is a wiring list of the entire **ER-MicroCIM** system. (This list does not include the communication wiring performed during the installation procedures.)




Figure 33: System Wiring

## MICRO CIM INTERCONNECTION WIRE LIST

<b>END1</b>	<b>END2</b>	<b>CABLE</b>	<b>LENGTH (mm)</b>	<b>DESCRIPTION</b>
CON PNL START- 23	TB28-2	#D40228-WHT		START
CON PNL STOP-25	TB29-2	#D40228-GRN		STOP
CON PNL AUTO/MAN-13	TB34-2	#D40228-BRN		AUTO/MAN
CON PNL EMG-13	TB36-2	#D40228-BLK		EMG3(COA)
CON PNL EMG-14	TB37-2	#D40228-YLW		EMG4(COA IN1)
CON PNL EMG-22	TB35-2	#D40228-ORN		EMG2(PLC IN15)
CON PNL EMG-21	TB14-2	#D40228-RED		EMG1(+24VDC)
D6-A	RL1-A			
D6-B	RL1-B			
I/O CARD J1-COMMON	TB36-1	#D40229-BLK		CONT A COMMON
I/O CARD J10-IN1	TB37-1	#D40229-RED		CONT A IN1
I/O CARD J2-C	TB18-1	#D40229-WHT		CONT A OUT 1 COM
I/O CARD J2-NO	TB2-1	#D40229-GRN		CONT A OUT 1 NO
MOTOR 1 RED	TB1-2	W104 RED	(#D40225)	MOTOR 1
MOTOR 2 BLK	TB8-4	W104 BLK	(#D40225)	MOTOR 2
PLC IN 0	TB20-1	#D411823-GRY	500	STA1-ID0
PLC IN 1	TB21-1	#D411823-WHT/BLK/ORN	500	STA1 ARID1
PLC IN 2	TB22-1	#D411823-WHT/BLK/RED	500	STA2-ID0
PLC IN 3	TB23-1	#D411823-WHT/BLK/BRN	500	STA2 ARID1
PLC IN 4	TB24-1	#D411823-WHT/BLK/YLW	500	STA3-ID0
PLC IN 5	TB25-1	#D411823-WHT/BLK/GRN	500	STA3 ARID1
PLC IN 6	TB26-1	#D411823-WHT/BLK/BLU	500	STA4-ID0
PLC IN 7	TB27-1	#D411823-WHT/BRN	500	STA4 ARID1
PLC IN 8	TB28-1	#D411823-WHT/BLU	500	START
PLC IN 9	TB29-1	#D411823-WHT/YLW	500	STOP
PLC IN 10	TB30-1	#D411823-WHT/ORN	500	RT-INPLACE
PLC IN 11	TB31-1	#D411823-WHT/GRY	500	LT-INPLACE
PLC IN 12	TB32-1	#D411823-WHT/PUR	500	UP-INPLACE
PLC IN13	TB33-1	#D411823-WHT/RED	500	DN-INPLACE
PLC IN14	TB34-1	#D411823-WHT/BLK	500	MANUAL
PLC IN15	TB35-1	#D411823-WHT/GRN	500	EMGCY
PLC COM IN1	TB17-1	#D411823-RED	500	GND BUS
PLC COM IN2	TB17-3	#D411823-BLK	500	GND BUS
PLC OUT 0	TB7-1	#D411823-BRN	500	PISTON 1
PLC OUT 1	TB6-1	#D411823-PUR	500	PISTON 2
PLC OUT 2	TB5-1	#D411823-YLW	500	PISTON 3
PLC OUT3	TB4-1	#D411823-BLU	500	PISTON 4
PLC OUT 4	TB3-1	#D411823-GRN	500	MOTOR
PLC COM OUT 1	TB16-1	#D411823-WHT	500	GND BUS
PLC COM OUT 2	TB16-3	#D411823-ORN	500	GND BUS
PLC PWR +24VDC	TB14-3	W104 RED (TWISTED P.)	(#D40227)	+24DVC BUS
PLC PWR COM	TB15-1	W104 BLK (TWISTED P.)		GND BUS
PLC CHASSIS GND	CHASSIS GND	#D40224	350	CHASSIS GND
PWR SPLY-BRN	TB14-4	PENDEL		+24DVC
PWR SPLY-BLU	TB15-2	PENDEL		COM
RL1-A1 RED	TB8-1	W103 RED		+24DVC
RL1-A2 BLK	TB3-2	W103 BLK		PLC OUT4
RL1-11 BLK	TB15-3	W104 BLK		MOT (+)
RL1-14 BLK	RL1-24	W104 BLK		
RL1-21 RED	TB1-1	W104 RED		MOTOR 1
RL1-22 RED	TB9-2	W104 RED		MOT(-)
RL1-24 BLK	RL1-14	W104 BLK		



<b>END1</b>	<b>END2</b>	<b>CABLE</b>	<b>LENGTH</b>	<b>DESCRIPTION</b>
SNSR FDR BRN	I/O CARD J1-+12VDC	SENSOR CABLE		CONTA 12VDC
SNSR FDR BLU	I/O CARD J1-COMMON	SENSOR CABLE		CONT A COMMON
SNSR FDR BLACK	I/O CARD J10-IN2	SENSOR CABLE		CONT A IN2
SNSR RT-RED	TB13-4	#D40223-RED		SNSR RT+
SNSR RT-WHT	TB20-2	#D40223-WHT		STA1-ID0
SNSR RT-GRN	TB21-2	#D40223-GRN		STA1 AR ID1
SNSR RT-BLK	TB30-2	#D40223-BLK		RT INPLACE
SNSR LT-RED	TB13-2	#D40222-RED		SNSR LT+
SNSR LT-WHT	TB22-2	#D40222-WHT		STA2-ID0
SNSR LT-GRN	TB23-2	#D40222-GRN		STA2 AR ID1
SNSR LT-BLK	TB31-2	#D40222-BLK		LT INPLACE
SNSR UP-RED	TB12-4	#D40223-RED		SNSR UP+
SNSR UP-WHT	TB24-2	#D40223-WHT		STA3-ID0
SNSR UP-GRN	TB25-2	#D40223-GRN		STA3 AR ID1
SNSR UP-BLK	TB32-2	#D40223-BLK		UP INPLACE
SNSR DN-RED	TB12-2	#D40222-RED		SNSR DN+
SNSR DN-WHT	TB26-2	#D40222-WHT		STA4-ID0
SNSR DN-GRN	TB27-2	#D40222-GRN		STA4 AR ID1
SNSR DN-BLK	TB33-2	#D40222-BLK		DN INPLACE
TB8-3	TB9-1	WAGO 260-402		JP1
TB9-3	TB10-1	WAGO 260-402		JP2
TB10-3	TB11-1	WAGO 260-402		JP3
TB11-3	TB12-1	WAGO 260-402		JP4
TB12-3	TB13-1	WAGO 260-402		JP5
TB13-3	TB14-1	WAGO 260-402		JP6
TB15-4	TB16-2	WAGO 260-402		JP7
TB16-4	TB17-2	WAGO 260-402		JP8
TB17-4	TB18-2	WAGO 260-402		JP9
TB18-4	TB19-2	WAGO 260-402		JP10
VF1-RED	TB9-4	#D40226-RED		+24DVC
VF2-BLK	TB2-2	#D40226-BLK		COA OUT1
VR1-RED	TB11-2	#D40226-RED		+24DVC
VR2-BLK	TB7-2	#D40226-BLK		PLC OUT0
VL1-RED	TB11-4	#D40226-RED		+24DVC
VL2-BLK	TB6-2	#D40226-BLK		PLC OUT1
VU1-RED	TB10-4	#D40226-RED		+24DVC
VU2-BLK	TB5-2	#D40226-BLK		PLC OUT2
VD1-RED	TB10-2	#D40226-RED		+24DVC
VD2-BLK	TB4-2	#D40226-BLK		PLC OUT3

## 8.4 Technical Drawings of Parts

### 8.4.1 Plexiglass Base




Figure 34: Plexiglass Base

<b>Material:</b>	PLEXIGLASS 113072
<b>Surf.Rough.:</b>	N9
<b>Fillet Rad.:</b>	0.2
<b>Break Edges:</b>	0.2 X 45°
<b>Dimensions:</b>	MM

## 8.4.2 Aluminum Cylinders




Figure 35: Aluminum Cylinder

<b>Material:</b>	ALUMINUM 6061
<b>Surf.Rough.:</b>	N9
<b>Fillet Rad.:</b>	0.2
<b>Break Edges:</b>	0.2 X 45°
<b>Dimensions:</b>	MM

---

## 8.5 Barcode Reader Setup

To set up the LS 6x20 barcode scanner for operation in the **ER-MicroCIM** cell, it must be programmed using the barcodes listed in the following table. These barcodes can be found in the section, “Programmer’s Guide,” of the *Product Reference Guide* for the LS 6x20 scanner. The barcodes must be scanned in the order in which they appear in the table.

*Note:* To prevent interference from adjacent barcodes on the same page, it may be useful to cut a hole in a blank sheet of paper and place it over the barcode before scanning. If you make a mistake when scanning, you must repeat the entire sequence from Step 1.

Step #	Name of Barcode to Scan	Pg. # in <i>LS6x20 Reference Guide</i>
1	SET DEFAULT	19
2	INTERLEAVED 2 OF 5 LENGTH 1 (Range 01–31)	22
3	0	23
4	6	23
5	ENTER	23
6	PARITY	28
7	SPACE	28
8	ENTER	28

This procedure sets the barcode scanner for the following setup:

RS232 parameters:      Baud rate 9600  
                                 8 data bits  
                                 2 stop bits  
                                 No parity  
                                 No handshake

Barcode type:            Interleaved 2 of 5, first length = 6

---

## **8.6 Known Problems**

### **8.6.1 Bug: Incorrect Status in Controller for ACL Program RVP**

The controller sometimes reports the status for program RVP as PEND (response to ACL command STAT). When this occurs, do the following from the ACL Control Panel:

- Enter the command A to abort all programs.
- Enter the command: RUN INITC.
- Enter the command STAT to make sure RVP now has the status DELAY.

### **8.6.2 Order Limitation**

Only one buffer at the ASRS/Assembly Station is available for an assembly task. Thus, in the Order Definition screen (Order Entry icon), you must enter 1 (one) both in the Initial Quantity column and in the Subsequent Quantity column. This will enable the system to properly handle a template which is returning to the ASRS/Assembly Station with a failed assembly.

In addition, the value in the Total Quantity column should not be greater than 4 (four). Although the ASRS can handle six parts, limiting the quantity to four will enable the system to complete the order even if two parts fail the quality control inspection.

The devices in the **ER-MicroCIM** have few maintenance requirements. Preventive maintenance is limited mostly to visual inspection and simple adjustments.

---

## **9.1 Hardware**

### **9.1.1 Conveyor**

No preventive maintenance is required.

For troubleshooting and repair procedures, refer to the *Programmable Controllers Operation Manual*.

### **9.1.2 Robot and Controller**

For maintenance, troubleshooting and repair procedures, refer to the *SCORBOT-ER Vplus User's Manual*.

### **9.1.3 Pneumatic System**

Make sure air pipes are securely fastened, and do not leak.

Make sure nominal pressure is 5-7 bar.

### **9.1.4 Electrical Wiring**

Make sure cables and wires are securely fastened and do not show signs of abrasion or wear.

---

## **9.2 Software and PCs**


### **9.2.1 OpenCIM Software**

For troubleshooting, refer to the *OpenCIM User's Manual*.

### **9.2.2 Vision System**

For troubleshooting, refer to the *ROBOTVISIONpro User's Manual*.

The individual devices in the **ER-MicroCIM** can be used for short study units, while the entire system itself can provide the basis for an extended course of study.



*Figure 36: MicroCIM Laboratory*

---

## **10.1 Modules**

### **10.1.1 Robot**

- Robot structure
- Robot arm movements
- Teach pendant control of robot arm
- Point definition
- Robot programming

### **10.1.2 Robot Mechanisms**

- Motors
- Encoders
- Microswitches
- Gears and transmissions
- End effectors

### **10.1.3 PID Control**

- Degrees of freedom
- Open-loop control
- Position and speed control
- Linear and circular path control
- PID control parameters
- “Ziglaer-Nicholas” method of control

### **10.1.4 Computer Communication**

- Baud rate
- Data bits
- Parity
- Stop bits
- Flow control
- Port address
- Interrupt request

### **10.1.5 Pneumatic Systems**

- Pneumatic power supply
- Pneumatic cylinder and piston
- Pneumatic logic control

### **10.1.6 Sensors and PLC Control**

- PLC digital input and output
- Magnetic, infrared and distance sensors
- DC motor control
- Step motor control
- Ladder diagram design
- PLC control of pneumatic system

### **10.1.7 Identification Systems**

- Binary to decimal code
- Decimal to binary code
- Magnetic code
- Barcode
- ASCII and binary data transmission on RS232 channel
- CIM template and pallet identification system



### 10.1.8 Vision and Quality Control

Lighting and optics

Image acquisition

Image processing

Pattern recognition

Applications: product identification, inspection, robot guidance

### 10.1.9 Manufacturing Software

Part definition

Order entry

Machine definition

Storage management

Logs

---

## 10.2 Courses

Eshed Robotec has developed a method for teaching modern manufacturing technologies, known as **AMT**: Advanced Manufacturing Technology Laboratory.

**AMT** is a four-semester academically based program, designed to provide high school students with a broad-based competency in modern manufacturing technologies. The program is designed with a modular and flexible curriculum, which systematically covers a variety of subjects and develops the students' knowledge and experience in these areas.

Each subject, or module, can be covered in 16 classroom hours. Students are divided into groups which concurrently study the various subjects, and simultaneously rotate to the next module. An instructor management system ensures that all students complete all material by the end of the semester.

Each semester begins with a 2-4 hour introductory presentation, and concludes with a 6-8 hour final project.

### 10.2.1 AMT: Semester I

- Introduction to the **ER-MicroCIM** (system components, stations, software).
- Introduction to CAD (when included in installation)
- Introduction to CNC (when included in installation)
- Materials Testing and Evaluation
- Pneumatic / Hydraulic Systems
- Introduction to Robotics

### **10.2.2 AMT: Semester II**

- Introduction to CAD (when included in installation)
- Sensors and PLC Control
- Mechanical Measurement and Quality Control
- Pneumatic / Hydraulic Systems
- Robot Mechanisms and Computer Communication

### **10.2.3 AMT: Semester III**

- Manufacturing Software
- Vision and Quality Control
- Introduction to FMS (when CNC included in installation)
- Identification Systems
- PID Control

### **10.2.4 AMT: Semester IV**

- Guided Project: Based on a set of projects developed by Eshed Robotec, the student will consider engineering, industrial and economic factors, and will design and produce several products. 30 hours
- Final Project: The student will be encouraged to take an entrepreneurial approach to design and produce an item. 60 hours.