

JobMaster Mechanical Training Bench



QUICK START GUIDE

For the New 00-1800 Series Benches

Catalog #34-8000-0016 Rev. A

intelitek ®

Copyright © 2019 Intelitek Inc.

Tel: (603) 625-8600

JobMaster Mechanical Bench Quick Start Guide

Fax: (603) 437-2137

Cat. # 34-8000-0016 Rev. A

November 2019

website: <http://www.intelitek.com>

email: info@intelitek.com

Intelitek software and documentation are available at <http://intelitekdownloads.com>.

All rights reserved. No part of this publication may be stored in a retrieval system, or reproduced in any way, including but not limited to photocopy, photography, magnetic, or other recording, without the prior agreement and written permission of the publisher. Program listings may be entered, stored, and executed in a computer system, but not reproduced for publication.

Every effort has been made to make this book as complete and accurate as possible. However, no warranty of suitability, purpose, or fitness is made or implied. Intelitek is not liable or responsible to any person or entity for loss or damage in connection with or stemming from the use of the software, hardware and/or the information contained in this publication.

Intelitek bears no responsibility for errors that may appear in this publication and retains the right to make changes to the software, hardware and manual without prior notice.

Table of Contents

1.	In This Guide	4
1.1.	Overview	4
1.2.	Version Update: Main Differences	4
2.	List of Accessories	5
3.	Assembly	6
3.1.	Assembling the Mobile Bench	6
3.2.	Assembling the Shelves	6
3.3.	Assembling the Working Surface	6
3.4.	Motor Controller and Safety Guard Assembly	9
4.	Operating the Motor	12
5.	Working with the Curriculum	16
5.1.	Overview	16
5.2.	Performing the Skill Drills	17

1. In This Guide

1.1. OVERVIEW

Thank you for purchasing the JobMaster Mechanical Training Bench for use in your classroom or laboratory. This guide is meant to help you assemble the bench and prepare it for use with the online learning curriculum.

While the experiments, images, and videos contained in the online learning curriculum refer to an older version of the Mechanical Training Bench (00-ME10 series), **the curriculum can easily be completed using this new 00-1800 series bench.** Therefore, this guide contains general instructions for how to complete the curriculum with the newer version of the Mechanical Bench and lists the basic differences between the versions of the Mechanical Bench.

1.2. VERSION UPDATE: MAIN DIFFERENCES

The main differences between this version of the Mechanical Bench and the previous version are related to:

- **Modularity:** This version of the Mechanical Bench includes plastic containers with equipment that can be placed on the shelves of the bench. Different levels of equipment may be purchased, and containers can be moved, interchanged, or stored elsewhere. For more information about the different levels of modularity, see Section 2 List of Accessories.
- **Safety:** With the introduction of a new magnetic key/lock system, the motor can only run when the plexiglass enclosure is securely in place. See Section 3.4 Motor Controller and Safety Guard Assembly for more information.
- **Motor Controller:** The motor controller has been updated. For instructions on its use, see Section 4 Operating the Motor.
- **Materials:** The previous version of the Mechanical Bench contained rigid metal racks and an inflexible working surface. The 00-1800 series is made up of more flexible and user-friendly materials.

For additional details, see Section 5 Working with the Curriculum.

2. List of Accessories

You may have purchased additional, optional Mechanical Training Bench accessories. You can find a list of these accessories in this table.

Part	Cat. No.	Level
Working Surface	00-1800-0002	1
Coupling Kit	10-1800-0002	1
Shaft & Bearing Kit	10-1800-0003	1
Accessories Kit 1	10-1800-0004	1
Sheave, Pulley, & Sprocket Kit	10-1800-0005	2
Motor/Speed Reducer Kit	10-1800-0006	2
Accessories Kit 2	10-1800-0007	2
Gear Kit	10-1800-0008	3
C-Brake/Speed Reducer Kit	10-1800-0009	3
Gearbox Kit	10-1800-0010	3
Tool Set	10-1800-0020	1
Mobile Bench	00-1800-0001	Optional
Shelf Set	10-1800-0001	Optional

3. Assembly

3.1. ASSEMBLING THE MOBILE BENCH


Unpack and assemble the mobile bench (00-1800-0001) according to the instructions in document 101969.

3.2. ASSEMBLING THE SHELVES

Assemble the shelf set (10-1800-0001) onto the mobile bench according to the instructions in document 101970.

3.3. ASSEMBLING THE WORKING SURFACE

The Mechanical Bench includes two main sections; the main mobile bench (00-1800-0001) with shelves (10-1800-0001), and the working surface (00-1800-002). The working surface must be secured to the top of the mobile bench at all four legs of the working surface. This section provides basic instructions for the assembly. For more additional technical instructions, see document 101970.




To assemble the benchtop:

1. With the help of at least one other person, place the benchtop on top of the mobile bench with the four legs of the working surface situated at the points indicated by the X's.




Note: Placement at the points shown above allows for the placement of a second working surface on top of the mobile bench.

2. Secure each of the legs of the working surface to the mobile bench in the following manner:
 - a. Slot an M8 nut into the slot of the mobile bench's profile near the location of one of the legs of the working surface (on the side of the leg's circular pocket).



- b. Slide an M8 screw through a leg fastener and tighten the fastener to the nut with an appropriate hex key. Do not tighten completely.



- c. Push the screw/fastener/nut assembly into the circular pocket of the working surface's leg.




- d. Perform steps a-c for all four working surface legs.
- e. Tighten all four M8 screws completely using the rounded end of the hex key.

3.4. MOTOR CONTROLLER AND SAFETY GUARD ASSEMBLY


The safety guard assembly (021216) and motor power controller (26-0000-0003) include a motor lock. The motor lock is a magnetic lock/key safety device. The lock has two magnetic read heads, one of which is wired to the controller, and the other is attached to the safety guard assembly. When the two read heads are separated, the controller is disabled and the motor (021217) cannot run. When the two read heads are coupled together, the controller is enabled, and the motor can run.

This section contains an overview of how to mount the controller and the safety guard assembly. For additional details, see document 101970.





Warning

 *Ensure that the motor controller is NOT connected to a power source before starting this procedure.*

To assemble the motor power controller and safety guard assembly:

1. Place the controller on the left side of the top shelf.



2. Slide the magnetic read head that is connected to the controller around the top of the mobile bench and through the corner hole of the working surface.



- Secure the read head to the top of the working surface using the included bracket and screws. Do not completely tighten the read head itself to the bracket at this point, as its height may have to be adjusted.



- Place the safety guard assembly on top of the working surface. Ensure that the two read heads are touching and aligned. If they are not, remove the safety guard and adjust the height of the read head connected to the controller. Replace the safety guard to confirm alignment.




- Remove the safety guard and completely fasten the lower magnetic read head to the bracket.


4. Operating the Motor

Motor operation is performed via the motor power controller. This section documents the basic operation of the controller.

⚠ Warning: *The controller has two voltage options. Ensure that you are using the correct voltage. To change the controller's voltage, see document 101976.*



For basic motor operation, the components labelled below are used:



Label	Component	Function
A	Controller input power switch (INPUT)	Sends single-phase power to the controller unit.
B	Controller power indicator lamp	The controller is powered with single-phase power when the lamp is illuminated.
C	Output power switch (OUTPUT ON/OFF)	Sends single-phase power brake output (middle) and motor control (left) sections of the controller.
D	Motor power on/off switch (MOTOR ON/OFF)	Sends single-phase power to the motor driver.
E	Motor power indicator lamp	The motor's driver is powered with single-phase when the lamp is on.
F	Motor start button (START)	Starts the motor. (Sends 3-phase power to the motor.)
G	Motor speed adjustment knob (MOTOR SPEED)	Adjusts the motor speed. (Adjusts the 3-phase power amplitude.)
H	Output to brake socket.	Connects to the brake plug and powers the brake. The brake is locked by default. When the brake is powered (when the output power switch [C] is on), the brake is released, allowing the motor shaft to run.



Warning

⚠ *Before beginning this procedure, ensure that the motor is properly secured to the working surface. For instructions on how to secure the motor, see course ME05: Belt Drives, Skill Drill 2 (document SG-ME05-02) in the online curriculum.*


⚠ *Ensure that the safety guard assembly is in place.*

To start the motor:

1. Turn the controller input power switch (A) on. The controller input indicator lamp (B) is illuminated.
2. Turn the controller output switch (C) on (upwards).
3. Turn the motor on/off switch (D) on (upwards). Power is sent to the motor and the motor power indicator lamp is illuminated (E).

⚠ *Ensure that motor speed knob is turned to a low speed.*

4. Press START (F) to start the motor.
5. Adjust the motor speed dial (G) as desired.



To stop the motor without applying the brake:

- Turn the MOTOR ON/OFF switch (D) off (downwards).

To stop the motor while applying the brake:

- Turn the OUTPUT ON/OFF switch (C) off (downwards).

i *Note: After stoppage of the motor for any reason (including removal of the safety guard), the START button (F) must be pressed to restart the motor.*

5. Working with the Curriculum

5.1. OVERVIEW


In the online learning curriculum (courses ME01 to ME13), instructions, images, and videos refer to the older version of the Mechanical Training Bench (00-ME10 series bench).

However, the principles for performing the experiments (skill drills) are the same for this newer version of the Mechanical Training Bench.


For example, instead of storing equipment on metal racks, equipment is stored in the plastic containers on the shelves.



00-1800 series with plastic containers



00-ME10 series with metal racks



00-1800 series example plastic container



00-ME10 series example metal rack

5.2. PERFORMING THE SKILL DRILLS

In the ME series skill drills (course experiments), images and videos refer to the 00-ME10 series Mechanical Training Bench. Performing the skill drills with the 00-1800 series hardware, however, is performed in the same manner atop the working surface. Parts are secured to the working surface by screwing them into the top of the surface via the surface's holes.

Consider this example where the motor and speed reducer are installed on the working surface. The procedure for securing and aligning the assembly is the same for both versions of the mechanical bench.



00-1800 series assembly



00-ME10 series assembly

This image of the Mechanical Training Bench's working surface from above provides a general map for where to secure various assemblies when performing the skill drills.

