

Technical Support	
Phone	(800) 221-2673
Fax	(604) 625-2137
Email	support@intelitek.com

# Accessory Installation Guide Shield Opener

Accessory	Shield opener
Name	
Accessory	011105
P/N	
Applicable to	BenchTurn 7000

# 1 Additional Requirements

To complete this installation you will require:

- 1. Scissors/utility knife
- 2. 3 mm Allen wrench
- 3. #2 Phillips head screwdriver
- 4. Small blade screwdriver (2 to 2.5 mm)

### 2 Unpacking Instructions


1. Open the crate and gently remove the contents.



2. Carefully cut the ties used to bind the air hoses.

## 3 Install the Shield Opener Assembly

- 1. Use a 3 mm Allen wrench to remove:
  - Seven pre-mounted socket head cap screws from the enclosure.
  - One pre-mounted socket head cap screw from the shield.



 Place the shield opener assembly on top of the BenchTurn 7000 enclosure.
Align the assembly as shown below.





Technical Support		
Phone	(800) 221-2673	
Fax	(604) 625-2137	
Email	support@intelitek.com	

3. Remove the cover of the assembly.



4. Connect the black air supply hose to the available receptacle on the solenoid valve.



5. Route the black hose and the control wires from the air shield assembly through the holes on the assembly's cover as shown.



- 6. Replace the cover of the assembly.
- Place the seven socket head cap screws (removed in step 1 above) through the holes around the assembly and into the enclosure. Finger-tighten only.
- 8. Remove the socket head cap screw that holds the "L" bracket to the piston bracket.



2



Technical Support	
Phone	(800) 221-2673
Fax	(604) 625-2137
Email	support@intelitek.com

 Place a socket head screw cap through the "L" bracket and tighten it to the shield. (This screw was removed in step 1 above.)



10. Use the socket head cap screw removed in step 8 above to attach the "L" bracket to the piston bracket, and tighten securely.

You may have to partially loosen the seven screws around the assembly in order to perform this step.



11. Tighten the seven screws around the assembly to secure the assembly to the enclosure.

12. Remove the magnetic door plate on the shield to disable the magnetic safety lock.



# 4 Install the Regulator

- 1. Unscrew the pre-mounted screws located on the left side of the BenchMill 7000 enclosure.
- 2. Use those screws to attach the regulator to the enclosure.




Installation Guide: Automatic Shield Opener for BenchTurn 7000



Technical	Support	
Phone	(800) 221-2673	
Fax	(604) 625-2137	
Email	support@intelitek.com	


3. Connect the blue and black air supply hoses to the color coded receptacles on the regulator as shown.



4. Connect the blue air hose to the building's air supply using the T-fitting supplied in the kit.

# 5 Connecting the Wiring


1. Connect the wires to the I/O panel at the side of the machine as outlined in the graphic and table below.




From Shield Opener Assembly	To Machine I/O Panel
24V A	24 V
24V B	24 V
OPEN	OUT
CLOSE	СОМ

### 6 The Software

1. Click Start → All Programs → CNCBase for Intelitek CNC → CNC Configuration.



2. Click the **Options** tab.



3. Click Reinstall.



4. Select Shield Opener.



5. Click Reinstall.



6. Click **OK** to close CNCBase.



## 7 Verify Proper Shield Operation

1. Launch CNCBase from your Start menu.



Installation Guide: Automatic Shield Opener for BenchTurn 7000



Technical Support	
Phone	(800) 221-2673
Fax	(604) 625-2137
Email	support@intelitek.com

2. Note which of the shield state buttons, located at the lower left side of the screen, is active (pressed in).



- 3. If the shield state indicated:
  - Does not match the current actual state of the shield on the machine, switch the two blue wires between SHIELD OPEN and SHIELD CLOSED.



 Does match the current actual state of the shield on the machine, the wiring is correct.

Installation complete.