

---

---

## ***Slotted Aluminum Table*** (Cat #1249)

### **Assembly Instructions**

Refer to the figure on the next page.

*You will need a 5 mm hex wrench with T-handle for the assembly.*

1. Attach the front beam (points A and B) to the side beams, with the non-slotted sides of the front and side beams facing up and out.
2. Attach the four leg beams (points C, D, E, F) to the side beams, with the non-slotted sides of the leg beams facing out.
3. Attach the rear beam (points G and H) to the side beams, with the non-slotted sides of the rear beam facing up and out.
4. Insert the table backboard (from above) into the slots of the rear leg beams, and slide the backboard into place. Loosen the screws if necessary to position the backboard, and tighten them when the backboard is properly positioned.
5. Insert the six brackets into the upper slots on the inside of the front and rear beams (3 brackets per beam). Space the brackets evenly across the beam.
6. Position the shelf, and attach it to the table by tightening the 6 bracket screws from below the beams.
7. Attach the feet to the table legs. Adjust the height and tighten the screws.
8. Slide the slotted table top into position, and tighten the screws.
9. Attach the four plastic covers to the exposed corners of the table top.
10. Make sure all beams are securely fastened.
11. Cover all holes with the small plastic caps.

**Intelitek Inc.**

444 East Industrial Park Drive  
Manchester, NH 03109-5317  
USA

Tel: (603) 625-8600

Fax: (603) 625-2137

**website:** [www.intelitek.com](http://www.intelitek.com)

**email:** [info@intelitek.com](mailto:info@intelitek.com)

